

**HAND PROGRAMMING SHEET
FOR
7900 PAGER**

1. Pager [OFF].
2. Insert battery while holding the [GREEN BUTTON]
3. Screen will display [MNL PROGRAM]
4. Press the [GREEN BUTTON] password will appear. [0000].
5. Press the [GREEN BUTTON] until the first Cap Code appears.
[ID1 ON 0300008]
6. Use the [GREEN BUTTON] to move from one digit to the next.
7. Use the [RIGHT ARROW] to change a digit
8. After setting the cap code and the cap code id [ID3] is flashing
use the [RIGHT ARROW] to move to the next cap code
9. After last cap code is set, Select correct baud rate using the
[RIGHT ARROW]
10. Press the [GREEN BUTTON] to display frequency. This should
not be changed unless told to do so.
11. Press the [GREEN BUTTON] to move through the frequency.
12. The next screen will show [PROGRAM YES?], press the
[GREEN BUTTON]. The screen will turn off.
13. The pager is now programmed.